

Kangaroo Golfstream PACER™ *automatic gear control*

Don't push or drag your PACER without putting it in free-wheeling mode. Push the center release button in both drive wheels, then slip the wheel outward from the chassis. Wheels will lock into the "free-wheel" position on the axle, for safe towing or pushing, with gears disengaged.



PACER with brake & distance timer

Quick Start Guide

KangarooGolfstream.com
(828) 436-2101
Mon.-Fri. 8-5 ET

GETTING STARTED



From folded position, pull up on handle until latch on center tube snaps into place.

To fold caddy, press latch on center tube and push down on the handle.



CaddyCell lithium battery goes sideways in tray on chassis. Secure with strap.

Plug power connector into port on chassis.



liquid crystal screen

control knob



To get going simply rotate dial to desired speed then press control knob. Speeds start at 0.0 and go up to 9.5 in increments of 0.5. PACER will have consistent speed across fairways and downhill slopes because of its automatic gear control. You can safely adjust speed while the caddy is moving.



To use distance timer, press control knob for approximately one second. When screen changes to DC choose 10, 20, or 30 yards and press yellow button to select.

You must choose distance and select quickly or screen will go back to the main speed control screen.

THINGS TO KNOW



- Always remove battery from caddy before charging.
- Be careful to protect breakable LCD (liquid crystal display) screen. When loading your caddy into the trunk of a car be sure nothing will fall onto or rub against the screen.
- To put PACER in free-wheeling mode, push release button on outside of wheel. Slide outward slightly on the axle. Release button to allow wheel to lock in the proper groove.
- To carry your Golfstream properly, grasp it from a side strut when folded flat. Magnet located on chassis will help keep caddy from unfolding.



release button



*Your caddy is warranted for 12 months from purchase date, to the original purchaser in USA or Canada, for defects in manufacture. Ordinary wear & tear from use on the golf course or in transport isn't covered, and damage due to misuse or abuse (**including failure to disengage gears while pulling or pushing**) isn't covered by warranty. Kangaroo reserves right to require return for inspection to its North Carolina facility, at claimant's expense, packed carefully using the original shipping carton. All claims require serial number as well as name of original purchaser.*

CaddyCell battery and charger are separately warranted.

Each Golfstream has a unique serial number, located behind the central strut below the hinge.



**Kangaroo Golf
111 Kangaroo Drive
Columbus, North Carolina 28722**

KangarooGolfstream.com